



Pos.	Artikelbeschreibung	Description of item	Artikel Nr./Item No.
1+2+10	Schraube z. Füllstandanzeige	Screw f. fill level indicator	EOA19014801
3 + 14	Füllstandanzeige f. A190148	Fill level indicator f. A190148	EOA19014803
	Füllstandanzeige f. A190167	Fill level indicator f. A190167	EOA19016703
	Füllstandanzeige f. A190198	Fill level indicator f. A190198	EOA19019803
4	Ablasshahn, komplett	Drain cock, complete	EOA19014804
8	Dichtung, Hütchendichtung	Sealing, cone seal	EOA19014808
9	Füllstandsanzeigerohr f. A190148	Degree tube f. A190148	EOA19014809
	Füllstandsanzeigerohr f. A190167	Degree tube f. A190167	EOA19016709
	Füllstandsanzeigerohr f. A190198	Degree tube f. A190198	EOA19019809
15	Ring, Kunststoff f. A190148, A190167	Ring, plastic f. A190148, A190167	EOA19014815
	Ring, Kunststoff f. A190198	Ring, plastic f. A190198	EOA19019815
16	Heizkörper z. Warmhalten	Heating element f. keeping warm	EOA19014816
17	Dichtung	Sealing	EOA19014817
18	Brühheizkörper m. Dichtung f. A190148, A190167	Heating element w. sealing f. A190148, A190167	EOA19014818
	Brühheizkörper m. Dichtung f. A190198	Heating element w. sealing f. A190198	EOA19019818
21	Sicherheitsthermostat	Safety thermostat	EOA19014821
22+23	Resetstift	Reset pin	EOA19014822
24	Gehäuse, unten f. A190148, A190167	Bottom housing f. A190148, A190167	EOA19014824
	Gehäuse, unten f. A190198	Bottom housing f. A190198	EOA19019824
25	Kontrolllampe, rot	Red indicator light	EOA19014825
26	Kontrolllampe, grün	Green indicator light	020006326
28	Abtropfgitter f. A190148, A190167	Drip grid f. A190148, A190167	EOA19014828
	Abtropfgitter f. A190198	Drip grid f. A190198	EOA19019828
29	Bodenplatte f. A190148, A190167	Bottom plate f. A190148, A190167	EOA19014829
	Bodenplatte f. A190198	Bottom plate f. A190198	EOA19019829
30+31	Stopper, Gummi	Stopper, rubber	EOA19014830
32	Griff z. Deckel	Handle f. lid	EOA19014832
34	Deckel m. Griff f. A190148, A190167	Lid w. handle f. A190148, A190167	EOA19014834
	Deckel m. Griff f. A190198	Lid w. handle f. A190198	EOA19019834
36	Wasserverteiler, lang	Long water distributor	EOA19014836
	Wasserverteiler, kurz	Short water distributor	EOA19019836
37	Filter f. A190148, A190167	Filter f. A190148, A190167	EOA19014837
	Filter f. A190198	Filter f. A190198	EOA19019837
38	Percolatorrohr f. A190148	Coffee tube f. A190148	EOA19014838
	Percolatorrohr f. A190167	Coffee tube f. A190167	EOA19016738
	Percolatorrohr f. A190198	Coffee tube f. A190198	EOA19019838
40	Griff z. Behälter f. A190148, A190167	Handle f. container f. A190148, A190167	EOA19014840
	Griff z. Behälter f. A190198	Handle f. container f. A190198	EOA19019840
44	Behälter f. A190148	Container f. A190148	EOA19014844
	Behälter f. A190167	Container f. A190167	EOA19016744
	Behälter f. A190198	Container f. A190198	EOA19019844
48	Dichtring	Seal ring	EOA19014848
49	Thermostat	Thermostat	EOA19014849
52	Verkabelung, innen	Inner wire	EOA19014852
54	Anschlusskabel f. A190148, A190167	Power cord f. A190148, A190167	EOA19014854
	Anschlusskabel f. A190198	Power cord f. A190198	EOA19019854
56	Schalter	Switch	EOA19014856
57	Bürste z. Reinigung	Cleaning brush	EOA19014857
58	Schaber, Metall	Scraper, metal	EOA19014858



Kaffeemaschine Bartscher
Pro II 40T/60T/100T
Artikel-Nr.: A190148, A190167
A190198

Ersatzteilliste
01.01.2017